

VeriFone Omni/Vx Series Retail Application



Customer Service: 1-908-516-5901 24 HR Help Desk Terminal Support: 1-908-516-5902 1-800-441-1490

	Sale
Idle Prompt	Swipe card, TAP/ WAVE card on
Password:	RFID reader or press [F2] for sale. Key in the appropriate password and press [ENTER].
1= Prev [F1] [Merchant 1] Next [F2] Slct [F3] Exit [F4]	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.
Merch Passwd:	Key in the merchant password and press [ENTER].
Swipe or Enter Account #:	Swipe card or key in the card # and press [ENTER].
Credt [F1] Debit [F2] Choose Card: EBT [F3]	Press [F1] for credit.
Exp Date (MMYY):	Key in the expiration date in MMYY format and press [ENTER].
Password:	Key in the appropriate password and press [ENTER] .
Card Present Yes [F1]	Press [F1] if card is present. Press [F2] if card is not present.
Choose Tran: Web [F1]	Press [F1] for a phone order. Press [F2] for a web sale.
Encrypted? Yes [F1] No [F2]	Press [F1] for encryption. Press [F2] for no encryption.
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press [ENTER].
[Account #] Yes [F1] Confirm No [F2]	Press [F1] if card # matches. Press [F2] to cancel transaction.
Imprint Card Press Enter Key	Press [ENTER]
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number: Clerk Id:	Key in the invoice # and press [ENTER].
Logon: Yes [F1]	Key in the derk ID# and press [ENTER]. Press [F1] to logon the clerk ID.
No [F2] Password:	Press [F2] to return to idle prompt. Key in the clerk password and
Amount: \$ 0.00	press [ENTER]. Key in the amount and press [ENTER].
Tax Amt: \$ 0.00	Key in the amount of tax and press
Yes [F1]	[ENTER] or press [ENTER] to bypass. Press [F1] to send duplicate.
Send Duplicate? No [F2] Password:	Press [F2] to cancel transaction. Key in the appropriate password
	and press [ÉNTÉR].
V-Code:	Key in the CVD code from back of card and press [ENTER] or press [ENTER] to bypass.
Code Present? Xread [F2]	Press [F1] if code is not present. Press [F2] if code is unreadable.
Address:	Key in the cardholder address and press [ENTER] or press [ENTER] to bypass.
Zip Code:	Key in the cardholder ZIP code and press [ENTER] or press [ENTER] to bypass.
Waiting for answer Please wait	(No action while processing)
Cash [F1] Credit [F2] X.XX Debit [F3] Payment Type SV [F4]	Select payment type and press [ENTER].
Customer Number:	Key in the cust. # and press [ENTER].
Tax Exempt? Yes [F1] No [F2]	Press [F1] if tax exempt. Press [F2] if not tax exempt.
Tax Amt: \$ 0.00	Key in the amount of tax and press [ENTER] to bypass.
Yes [F1] Pmt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.
Amt Due: \$ xx.xx Enter to confirm	Press [ENTER] to begin sale trans. Press [CANCEL] to return to idle prompt.

Auth Only	
Idle Prompt	Press [ARROW] hot key twice.
EBT Bal Inq [F1] Auth Only [F2] Phone Order [F3] Other Setup [F4]	Press [F2] for auth only.
Password:	Key in the appropriate password and press [ENTER] .
1= Prev [F1] [Merchant 1] Next [F2] Slct [F3] Exit [F4]	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.
Merch Passwd:	Key in the merchant password and press [ENTER] .
Swipe or Enter Account #:	Swipe card, TAP/WAVE card on RFID reader or key in the card # and press [ENTER] .
Credt [F1] Choose Card: Debit [F2]	Press [F1] for credit.
Exp Date (MMYY):	Key in the expiration date in MMYY format and press [ENTER] .
Password:	Key in the appropriate password and press [ENTER] .
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press [ENTER].
[Account #] Yes [F1] Confirm No [F2]	Press [F1] if card # matches Press [F2] to cancel transaction.
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number:	Key in the invoice # and press [ENTER].
Clerk Id:	Key in the clerk ID # and press [ENTER].
Logon: Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.
Password:	Key in the clerk password and press [ENTER].
Amount: \$ 0.00	Key in the amount and press [ENTER].
V-Code:	Key in the CVD code from back of card and press [ENTER] or press [ENTER] to bypass.
No [F1] Code Present? Xread [F2]	Press [F1] if code is not present. Press [F2] if code is unreadable.
Address:	Key in the cardholder address and press [ENTER] or press [ENTER] to bypass.
Zip Code:	Key in the cardholder ZIP code and press [ENTER] or press [ENTER] to bypass.
Waiting for answer Please wait	(No action while processing)
Yes [F1] Prnt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

Force Sale	
Idle Prompt	Press [ARROW] hot key.
Refund [F1] Force [F2] Reprint [F3] Check [F4]	Press [F2] for force.
Password:	Key in the appropriate password and press [ENTER].
1= Prev [F1] [Merchant 1] Next [F2]	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.
Merch Passwd:	Key in the merchant password and press [ENTER].
Swipe or Enter Account #:	Swipe card, TAP/WAVE card on RFID reader or key in the card # and press [ENTER].
Credt [F1] Debit [F2] Choose Card: EBT [F3]	Press [F1] for credit.
Exp Date (MMYY):	Key in the expiration date in MMYY format and press [ENTER].
Password:	Key in the appropriate password and press [ENTER].
Sale [F1] Phone [F2] Choose Tran: Web [F3]	Press [F1] for a sale. Press [F2] for a phone order. Press [F3] for a web sale.
Yes [F1] Encrypted? No [F2]	Press [F1] for encryption. Press [F2] for no encryption.
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press [ENTER].
[Account #] Yes [F1] Confirm No [F2]	Press [F1] if card # matches. Press [F2] to cancel transaction.
Imprint Card Press Enter Key	Press [ENTER].
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number:	Key in the invoice # and press [ENTER].
Clerk ld:	Key in the clerk ID # and press [ENTER].
Logon: Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.
Password:	Key in the clerk password and press [ENTER].
Amount: \$ 0.00	Key in the amount and press [ENTER].
Tax Amt: \$ 0.00	Key in the amount of tax and press [ENTER] or press [ENTER] to bypass.
Yes [F1] Send Duplicate? No [F2]	Press [F1] to send duplicate. Press [F2] to cancel transaction.
Password:	Key in the appropriate password and press [ENTER].
Appr Code:	Key in the authorization # and press [ENTER].
Yes [F1] Prnt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

	Refund
Idle Prompt	Press [ARROW] hot key.
Refund [F1] Force [F2] Reprint [F3] Check [F4]	Press [F1] for refund.
Password:	Key in the appropriate password and press [ENTER] .
1=	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.
Merch Passwd:	Key in the merchant password and press [ENTER].
Swipe or Enter Account #:	Swipe card, TAP/WAVE card on RFID reader or key in the card # and press [ENTER].
Credt [F1] Debit [F2] Choose Card: EBT [F3]	Press [F1] for credit.
Exp Date (MMYY):	Key in the expiration date in MMY\ format and press [ENTER].
Password:	Key in the appropriate password and press [ENTER] .
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press [ENTER] .
[Account #] Yes [F1] Confirm No [F2]	Press [F1] if card # matches. Press [F2] to cancel transaction.
Sale [F1] Choose Tran: Web [F2]	Press [F1] for a sale. Press [F2] for a web sale.
Yes [F1] Encrypted? No [F2]	Press [F1] for encryption. Press [F2] for no encryption.
Imprint Card Press Enter Key	Press [ENTER]
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number:	Key in the invoice # and press [ENTER].
Clerk Id:	Key in the clerk ID # and press [ENTER].
Logon: Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.
Password:	Key in the clerk password and press [ENTER].
Amount: \$ 0.00	Key in the amount and press [ENTER].
Tax Amt: \$ 0.00	Key in the amount of tax and press [ENTER] or press [ENTER] to bypass
Yes [F1] Send Duplicate? No [F2]	Press [F1] to send duplicate. Press [F2] to cancel transaction.
Password:	Key in the appropriate password and press [ENTER].
Yes [F1] Prnt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

v	58
D	ebit Sale
Idle Prompt	Swipe debit card at idle prompt.
Password:	Key in the appropriate password and press [ENTER].
1= Prev [F1] [Merchant 1] Next [F2]	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.
Merch Passwd:	Key in the merchant password and press [ENTER].
Debit [F1] Choose Card: EBT [F2]	Press [F1] for debit.
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number:	Key in the invoice # and press [ENTER].
Clerk Id:	Key in the clerk ID # and press [ENTER].
Logon: Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.
Password:	Key in the clerk password and press [ENTER].
Amount: \$ 0.00	Key in the amount and press [ENTER].
Tax Amt: \$ 0.00	Key in the amount of tax and press [ENTER] or press [ENTER] to bypass.
CashBack: \$ 0.00	Key in the CashBack amount and press [ENTER] to bypass.
Yes [F1] Send Duplicate? No [F2]	Press [F1] to send duplicate. Press [F2] to cancel.
Password:	Key in the appropriate password and press [ENTER].
Enter PIN on PINPad	Customer keys PIN # on PIN pad and presses [ENTER].
Waiting for answer Please wait	(No action while processing)
Yes [F1] Prnt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

Debit Refund	
ldle Prompt	Press [ARROW] hot key.
Refund Force Reprint Check	[F2] [F3]
Password:	Key in the appropriate password and press [ENTER].
Merch Passwd:	Key in the merchant password and press [ENTER].
Swipe or Enter Account #:	Swipe card.
Debit Choose Card: EBT	
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number:	Key in the invoice # and press [ENTER].
Clerk Id:	Key in the clerk ID # and press [ENTER].

continued next column

	Debit Refund (Continued)	
Logon:	Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.
Password:		Key in the clerk password and press [ENTER].
Amount:	\$ 0.00	Key in the amount and press [ENTER].
Tax Amt:	\$ 0.00	Key in the amount of tax and press [ENTER] or press [ENTER] to bypass.
Send Duplicat	Yes [F1] e? No [F2]	Press [F1] to send duplicate. Press [F2] to cancel.
Password:		Key in the appropriate password and press [ENTER].
Enter PIN on F	PINPad	Customer keys PIN # on PIN Pad and presses [ENTER].
Waiting for an Please wait	swer	(No action while processing)
Prnt Cust Cop	Yes [F1] y? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter K	ey	Press [ENTER] to print a second copy of the receipt.

FRT Sale	e - Cash Benefit
Idle Prompt	Swipe EBT card at idle prompt or press [F2] for sale.
Password:	Key in the appropriate password and press [ENTER].
1=	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.
Merch Passwd:	Key in the merchant password and press [ENTER].
Swipe or Enter Account#	Swipe card or key in the account # and press [ENTER].
Debit [F1] Choose Card: EBT [F2]	Press [F2] for EBT.
Exp Date (MMYY):	Key in the expiration date in MMYY format and press [ENTER].
Password:	Enter password and press [ENTER].
Cash [F1] Trans Type: Food [F2]	Press [F1] for cash.
Imprint Card Press Enter Key	Press [ENTER]
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number:	Key in the invoice # and press [ENTER].
Clerk ld:	Key in the clerk ID # and press [ENTER].
Logon: Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.
Password:	Key in the clerk password and press [ENTER].
Amount: \$ 0.00	Key in the amount and press [ENTER].
CashBack: \$ 0.00	Key in the CashBack amount and press [ENTER].
Yes [F1] Send Duplicate? No [F2]	Press [F1] to send duplicate. Press [F2] to cancel.
Password:	Key in the appropriate password and press [ENTER].
Enter PIN on PINPad	Customer keys PIN # on PIN pad and presses [ENTER].
Yes [F1] Prnt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

EBT Sale	e - Food Stamp
Idle Prompt	Swipe EBT card at idle prompt or press [F2] for sale.
Password:	Key in the appropriate password and press [ENTER].
1= Prev [F1] [Merchant 1] Next [F2] Slct [F3] Exit [F4]	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.
Merch Passwd:	Key in the merchant password and press [ENTER] .
Swipe or Enter Account #	Swipe card or key in the account # and press [ENTER].
Choose Card: Debit [F1]	Press [F2] for EBT.
Exp Date (MMYY):	Key in the expiration date in MMYY format and press [ENTER].
Password:	Enter password and press [ENTER].
Cash [F1] Trans Type: Food [F2]	Press [F2] for food.
Imprint Card Press Enter Key	Press [ENTER]
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number:	Key in the invoice # and press [ENTER]
Clerk ld:	Key in the clerk ID # and press [ENTER].
Logon: Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.
Password:	Key in the clerk password and press [ENTER] .
Amount: \$ 0.00	Key in the amount and press [ENTER].
Yes [F1] Send Duplicate? No [F2]	Press [F1] to send duplicate. Press [F2] to cancel.
Password:	Key in the appropriate password and press [ENTER].
Enter PIN on PINPad	Customer keys PIN # on PIN pad and presses [ENTER].
Yes [F1] Prnt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

Idle Prompt	Press [ARROW] hot key.
Refund [F1] Force [F2] Reprint [F3] Check [F4]	Press [F2] for force.
Password:	Key in the appropriate password and press [ENTER] .
1=	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.
Merch Passwd:	Key in the merchant password and press [ENTER].
Swipe or Enter Account#	Swipe card or key in the account # and press [ENTER].
Debit [F1] Choose Card: EBT [F2]	Press [F2] for EBT
Exp Date (MMYY):	Key in the expiration date in MMYY format and press [ENTER].
Password:	Enter password and press [ENTER].
Cash [F1] Trans Type: Food [F2]	Press [F1] for cash.
Imprint Card Press Enter Key	Press [ENTER].
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number:	Key in the invoice # and press [ENTER].
Clerk Id:	Key in the clerk ID # and press [ENTER].
Logon: Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.
Password:	Key in the clerk password and press [ENTER].
Appr Code:	Key in the authorization # and press [ENTER].
Voucher number:	Key in the voucher # and press [ENTER].
Amount: \$ 0.00	Key in the amount and press [ENTER].
CashBack: \$ 0.00	Key in the CashBack amount and press [ENTER].
Yes [F1] Send Duplicate? No [F2]	Press [F1] to send duplicate. Press [F2] to cancel.
Password:	Key in the appropriate password and press [ENTER] .
Yes [F1] Prnt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

EBT Force - Food Stamp		
Idle Prompt	Press [ARROW] hot key.	
Refund [F1]	Press [F2] for force.	
Force [F2] Reprint [F3] Check [F4]		
Password:	Key in the appropriate password and press [ENTER].	
1= Prev [F1] [Merchant 1] Next [F2] Slct [F3] Exit [F4]	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.	
Merch Passwd:	Key in the merchant password and press [ENTER].	
Swipe or Enter Account #	Swipe card or key in the account # and press [ENTER].	
Debit [F1] Choose Card: EBT [F2]	Press [F2] for EBT,	
Exp Date (MMYY):	Key in the expiration date in MMYY format and press [ENTER].	
Password:	Enter password and press [ENTER].	
Cash [F1] Trans Type: Food [F2]	Press [F2] for food.	
Imprint Card Press Enter Key	Press [ENTER].	
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.	
Invoice Number:	Key in the invoice # and press [ENTER].	
Clerk Id:	Key in the clerk ID # and press [ENTER].	
Logon: Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.	
Password:	Key in the clerk password and press [ENTER].	
Appr Code:	Key in the authorization # and press [ENTER].	
Voucher number:	Key in the voucher # and press [ENTER].	
Amount: \$ 0.00	Key in the amount and press [ENTER].	
Yes [F1] Send Duplicate? No [F2]	Press [F1] to send duplicate. Press [F2] to cancel.	
Password:	Key in the appropriate password and press [ENTER].	
Yes [F1] Pmt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.	
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.	
1,		

EBT Refund - Food Stamp	
Idle Prompt	Press [ARROW] hot key.
Refund [F1] Force [F2] Reprint [F3] Check [F4]	Press [F1] for refund.
Password:	Key in the appropriate password and press [ENTER].
1= Prev [F1] [Merchant 1] Next [F2] Slct [F3] Exit [F4]	Press [F1] for previous merchant. Press [F2] for next merchant. Press [F3] to select displayed merchant. Press [F4] to exit.
Merch Passwd:	Key in the merchant password and press [ENTER].
Swipe or Enter Account #	Swipe card or key in the account # and press [ENTER].
Choose Card: Debit [F1]	Press [F2] for EBT,
Exp Date (MMYY):	Key in the expiration date in MMYY format and press [ENTER].
Password:	Enter password and press [ENTER].
Imprint Card Press Enter Key	Press [ENTER].
Cust Ref #:	Key in the customer reference # and press [ENTER] or press [ENTER] to bypass.
Invoice Number:	Key in the invoice # and press [ENTER].
Clerk Id:	Key in the clerk ID # and press [ENTER].
Logon: Yes [F1] No [F2]	Press [F1] to logon the clerk ID. Press [F2] to return to idle prompt.
Password:	Key in the clerk password and press [ENTER].
Amount: \$ 0.00	Key in the amount and press [ENTER].
Yes [F1] Send Duplicate? No [F2]	Press [F1] to send duplicate. Press [F2] to cancel.
Password:	Key in the appropriate password and press [ENTER].
Enter PIN on PINPad	Customer keys PIN # on PIN pad and presses [ENTER].
Yes [F1] Pmt Cust Copy? No [F2]	Press [F1] to print customer copy. Press [F2] to return to idle prompt.
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

EBT Balance Inquiry	
Idle Prompt	Press [ARROW] hot key twice.
EBT Bal Inq [F′ Auth Only [F′ Phone Order [F′ Other Setup [F′	2] 3]
Password:	Key in the appropriate password and press [ENTER].
1= Prev [F' [Merchant 1] Next [F2 Slct [F3 Exit [F4	2] Press [F2] for next merchant. 3] Press [F3] to select displayed
Merch Passwd:	Key in the merchant password and press [ENTER].
Swipe or Enter Account#	Swipe card or key in the account # and press [ENTER].
Exp Date (MMYY):	Key in the expiration date in MMYY format and press [ENTER].
Password:	Enter password and press [ENTER].
Cash [F' Trans Type: Food [F2	
Clerk Id:	Key in the clerk ID # and press [ENTER].
Logon: Yes [F ² No [F2	
Password:	Key in the clerk password and press [ENTER].
Enter PIN on PINPad	Customer keys PIN # on PIN pad and presses [ENTER].
Yes [F1 Prnt Cust Copy? No [F2	
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

	Void
Idle Prompt	Press [F4] for void.
Password:	Key in the appropriate password and press [ENTER].
1= Prev [F1 [Merchant 1] Next [F2 Slct [F3 Exit [F4	Press [F2] for next merchant. Press [F3] to select displayed
Merch Passwd:	Key in the merchant password and press [ENTER].
Auth#[F1] Select Batch Settl#[F2]	
Yes [F1] Void Last Trans? No [F2]	
Inv #[F3 Retrieve by: Acct #[F4	
Invoice Number:	Key in the invoice # and press [ENTER].
Last 4 digits:	Key in the last 4 digits of the card # and press [ENTER].
Yes [F1] [Account #] No [F2] \$ xx.xx Next [F3]	Press [F2] to return to idle prompt.
Yes [F1] Pmt Cust Copy? No [F2]	
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

Reprint	
Idle Prompt	Press [ARROW] hot key.
Refund [F1] Force [F2] Reprint [F3] Check [F4]	Press [F3] for reprint.
Password:	Key in the appropriate password and press [ENTER].
REPRINT Last Receipt [F2] Any Receipt [F3]	Press [F2] to print last receipt Press [F3] to print other receipt
Invoice Number:	Key in the invoice # and press [ENTER].
Yes [F1] Prnt Cust Copy? No [F2]	Press [F1] to print customer copy Press [F2] to return to idle prompt
Tear Receipt Press Enter Key	Press [ENTER] to print a second copy of the receipt.

Clerk Management - Add Clerk	
Idle Prompt	Press [ARROW] hot key three times.
Clerk Setup [F1] Store/Forward [F2] Help [F3]	Press [F1] for clerk setup.
Password:	Key in the appropriate password and press [ENTER].
CONFIGURE CLERK Log On Clerk [F2] Log Off Clerk [F3] Add Clerk [F4]	Press [F4] to add clerk to terminal
Password:	Key in the appropriate password and press [ENTER].
Clerk Id:	Key in the ID # of the clerk and press [ENTER].
Password:	Key in the new clerk password and press [ENTER].
Reenter:	Key in the new password again for confirmation and press [ENTER].
Clerk Id:	Prompt will continue to display until [CLEAR] is pressed to exit. Repeat for each clerk being added.

Clerk Management - Log On/Off Clerk	
Idle Prompt	Press [ARROW] hot key twice.
Clerk Setup [F1] Store/Forward [F2] Help [F3]	Press [F1] for clerk setup.
Password:	Key in the appropriate password and press [ENTER].
CONFIGURE CLERK Log On Clerk [F2] Log Off Clerk [F3] Add Clerk [F4]	Press [F2] to log on clerk. Press [F3] to log off clerk.
Clerk Id:	Key in the ID # of the clerk and press [ENTER].
Password:	Key in the clerk password and press [ENTER].
Logoff/on is successful	Terminal displays confirmation of logon/off and returns to the idle prompt.

Clerk Management - Delete Clerk	
Idle Prompt	Press [ARROW] hot key three times.
Clerk Setup [F1] Store/Forward [F2] Help [F3]	Press [F1] for clerk setup.
Password:	Key in the appropriate password and press [ENTER].
CONFIGURE CLERK Log On Clerk [F2] Log Off Clerk [F3] Add Clerk [F4]	Press [ARROW] hot key for more options.
Modify Clerk [F1] Delete Clerk [F2] Clear Clerk [F3]	Press [F2] for delete clerk.
Password:	Key in the appropriate password and press [ENTER]
Clerk Id:	Key in the ID # of the clerk and press [ENTER].
Password:	Key in the clerk password and press [ENTER].
Clerk Id:	Prompt will continue to display until [CLEAR] is pressed to exit. Repeat for each clerk being deleted.

Clerk Management - Modify Clerk	
Idle Prompt	Press [ARROW] hot key three times.
Clerk Setup [F1] Store/Forward [F2] Help [F3]	Press [F1] for clerk setup.
Password:	Key in the appropriate password and press [ENTER].
CONFIGURE CLERK Log On Clerk [F2] Log Off Clerk [F3] Add Clerk [F4]	Press [ARROW] hot key for more options.
Modify Clerk [F1] Delete Clerk [F2] Clear Clerk [F3]	Press [F1] for modify clerk.
Password:	Key in the appropriate password and press [ENTER].
Clerk Id:	Key in the ID # of the clerk and press [ENTER].
Clk Password:	Key in the appropriate clerk password and press [ENTER].
Old Pass:	Key in the old clerk password and press [ENTER].
New Pass:	Key in the new clerk password and press [ENTER].
Reenter:	Key in the new password again for confirmation and press [ENTER].
Clerk Id:	Prompt will continue to display until [CLEAR] is pressed to exit.

Cterk Manag	ement - Clear Clerk
Idle Prompt	Press [ARROW] hot key three times.
Clerk Setup [F1] Store/Forward [F2] Help [F3]	Press [F1] for clerk setup.
Password:	Key in the appropriate password and press [ENTER].
CONFIGURE CLERK Log On Clerk [F2] Log Off Clerk [F3] Add Clerk [F4]	Press [ARROW] hot key for more options.
Modify Clerk [F1] Delete Clerk [F2] Clear Clerk [F3]	Press [F3] for clear clerk.
Password:	Key in the appropriate password and press [ENTER].
Clerk tls cleard	Terminal confirms that clerks have been cleared and returns to the idle prompt

Clerk Management - Clerk Reports	
Idle Prompt	Press [REPORTS] hot key.
Password:	Key in the appropriate password and press [ENTER].
REPORTS Totals Report [F2] Detail Report [F3] Clerk Reports [F4]	Press [F4] for clerk reports.
CLERK REPORTS Totals Report [F2] Detail Report [F3] Shift Reports [F4]	Press [F2] for clerk totals. Press [F3] for clerk detail. Press [F4] for shift report. Press [ARROW] for more options
Clerk Table [F1] Unadjst Report [F2] IRS Tip Report [F3] Discount Tip [F4]	Press [F1] for clerk table. Press [F2] for unadjusted trans. Press [F3] for clerk IRS tip report. Press [F4] for discount tips.
One [F1] All [F2] Cirk Rpt Options	Press [F1] for single clerk detail. Press [F2] for all clerk detail.
Clerk ld:	Key in the ID # of the clerk and press [ENTER].
Clerk Report:	Report prints

Manual Shift Close		
Idle Prompt		Press [1].
Password:		Key in the appropriate password and press [ENTER].
Increment Shift	Yes [F1] t# No [F2]	Press [F1] to increment shift #. Press [F2] for other options.
Reset Shift#	Yes [F1] No [F2]	Press [F1] to reset shift # to 1. Press [F2] to continue with current shift.
Shift#is X		Shift # is displayed and terminal returns to idle prompt.

Reports	
Idle Prompt	Press [REPORTS] hot key.
Password:	Key in the appropriate password and press [ENTER].
REPORTS Totals Report [F2] Detail Report [F3] Clerk Reports [F4]	Press [F2] for totals report. Press [F3] for details report. Press [F4] for clerk report. Press [ARROW] for more reports
Batch Review [F1] Batch History [F2] Terminal Rpts [F3] Merchant Report [F4]	Press [F1] for batch review. Press [F2] for batch history. Press [F3] for terminal reports. Press [F4] for merchant report.
[Name of Report]	Report prints.

Viewing Batch Totals	
Idle Prompt	Press [REPORTS] hot key.
Password:	Key in the appropriate password and press [ENTER].
REPORTS Totals Report [F2] Detail Report [F3] Clerk Reports [F4]	8
Batch Review [F1] Batch History [F2] Terminal Rpts [F3] Merchant Report [F4]	
Password:	Key in the appropriate password and press [ENTER].
BATCH REVIEW Totals Review [F2] Detail Review [F3]	
1= Prev [F1] [Merchant 1] Next [F2]	Press [F2] for next merchant. Press [F3] to select displayed
Merch Passwd:	Key in the merchant password and press [ENTER].
Prev [F1] Next [F2] Host: [Paym] Slct [F3] Exit [F4]	Press [F2] for next host. Press [F3] to view totals for host
Host: [Paym] Sales: \$ xx.xx Refunds: \$ xx.xx Total: \$ xx.xx	

	Se	ttlement	
Idle Prompt		Press [F3] for settlement.	
Password:		Key in the appropriate password and press [ENTER].	
Sales: \$ xx.xx Refunds: \$ xx.xx Total: \$ xx.xx Enter to confirm * xx.xx		Confirm totals, press [ENTER]	
Sales:	\$ 00.00	Key in the sales total and press [ENTER].	
Refunds:	\$ 00.00	Key in the refund total and press [ENTER].	
Total:	\$ 00.00	Key in the batch total and press [ENTER]	
Settle Neg BatchYes [F1] No [F2]		Press [F1] to settle neg. batch Press [F2] to return to idle prompt	
Password:		Key in the appropriate password and press [ENTER].	
Waiting for answer Please wait		(No action while processing)	
Settlement Successful		Settlement report prints and terminal returns to idle prompt.	

AVS Response Codes

Password:	Key in the appropriate password and press [ENTER].	Visa	Description
REPORTS Totals Report [F2] Detail Report [F3] Clerk Reports [F4]	Press [ARROW] hot key for more reports.	A Address & 5-digit or 9-digit Z A Address matches, ZIP code of S AVS not supported at this time.	oes not e (Domestic only)

- R Issuer's authorization system is unavailable, try again later (Domestic only)
- U Unable to perform address verification because either address information is unavailable or Issuer does not
- support AVS (Domestic only) Z Either 5-digit or 9-digit ZIP matches, address does not or
- not included in request
- N Neither the ZIP nor the address matches
- B Address matches, ZIP not verified
- ZIP matches, address not verified
- Address and ZIP code not verified due to incompatible formats.
- D Address and ZIP code match (International only)
- G Address not verified for International transaction (International only)
- Address not verified (International only)
- M Address and ZIP code match (International only)

MasterCard Description

- Y Exact, all digits match, 5-digit ZIP code
- A Address matches, ZIP code does not
- S AVS not supported at this time
- R Retry, system unable to process
- U No data from issuer/Authorization system Z 5-digit ZIP code matches, but address does not
- N Neither the ZIP nor the address matches
- W For U.S. addresses, 9-digit ZIP code matches, but address does not; for address outside of U.S., the ZIP code matches, address does not
- X Exact, all digits match, 9-digit ZIP code

Description Discover

- Y Address only matches
- A Address and 5-digit ZIP code match
- S AVS not supported at this time
- U Retry, system unable to process
- Z 5-digit ZIP code matches, but address does not
- N Neither the ZIP nor the address matches
- W No data from issuer/authorization system
- X Address and 9-digit ZIP code match
- T 9-digit ZIP code matches, but address does not

American Express Description

- Yes, address and ZIP code are both correct
- A Address only is correct
- B AVS not supported at this time
- R System unavailable; retry
- U The necessary information is not available, account number is neither U.S. nor Canadian
- Z ZIP code only is correct
- N Neither the ZIP nor the address matches

